



## FAQ PY118 : 作成した surface を削除する

PY118\_sample01.py



PY118\_sample02.py




## FAQ PY118 : 作成した surface を削除する

```
47 ↓  
48 for i in range(1, nCoord+1, 1) : ↓  
49 ↓  
50     print ("-----") ↓  
51     strCurrentZ="CurrentZ: %7.5f ￥n " % CurrentZ ↓  
52     print strCurrentZ, ↓  
53 ↓  
54 ↓  
55     ## define coordinate surface table ↓  
56     coord_table = { ↓  
57         'dataset' : 1, ↓  
58         'scalar_func' : "temperature", ↓  
59         'transparency' : 0.5, ↓  
60         'axis' : "Z", ↓  
61         #'Z_axis' : [ 'current' : 0.0127], ↓  
62         'Z_axis' : [ 'current' : CurrentZ], ↓  
63         'display_type' : "smooth_shading", ↓  
64     } ↓  
65 ↓  
66     ## create coordinate surface ↓  
67     crd_handle=create_coord(coord_table) ↓  
68 ↓  
69     ## save image files ↓  
70     strCmd="PRINT GRAPHICS JPEG sample02_%3.3d.jpg ￥n " % i ↓  
71     fv_script(strCmd) ↓  
72 ↓  
73     ## clear dictionary ↓  
74     delete(crd_handle) ↓  
75 ↓  
76     CurrentZ=CurrentZ+deltaZ ↓  
77 ↓  
78 #end ↓  
79 ↓
```

handle 付きで  
Coordinate surface 作成

delete 命令

### Sample02: 毎loop おきに 旧 surface 追加



### Sample02: 毎loop おきに 旧 surface 削除

